

PXF Lighting 73 Jutrzenki Street 02-230 Warsaw


2 +48 22 33 44 000, **3** +48 22 33 44 033







Power [W] Weight [kg] L [mm] A [mm] 1x14/24 (T5) 684 620 1,2 1x8 (T5) 425 361 0,8 9 (LED) 394 330 0,8 17 (LED) 684 620 1,1

LED



- a) Slide the housing onto the handles, tighten the mounting screws;
- b) Install the diffuser;
- c) Disconnect the power in the circuit the fixture will be installed in;
- d) Carefully take the fixture out of the box;
- e) Dismount the diffuser, next, loosen the two M4 screws;
- f) Pull out the wall joints;
- g) Drill the holes in the wall accordingly to the spacing shown in the installation drawing, put the dowels in the holes
- h) Screw the handles to the wall;
- i) Install the light source (applies only to T5)
- j) Connect power supply wires to the connector in the luminaire accordingly to the markings;





Important warnings:

The manufacturer cannot be considered liable for any damages deriving from improper, wrong and unreasonable use of the fitting.

Luminaries may be installed by qualified personnel only.

To guarantee safety of fixture functions, please assembly according to instruction.

Any manipulation inside the luminaire when power supply is on causes the risk of electric shock.

Manufacturer is not responsible for any flaws caused by avoid using this manual.

Manufacturer reserves a right to change the construction of the product.

Do not assembly in places without air circulation.

